

## **Installation Guide for Lightweight Front LIP BMW F22**

### **Discharge tooling Equipment:**

- Lightweight Spoilerlip
- Cordless screwdriver (if possible)
- Hex-wrench (4mm)
- Screw wrench (Torx and cross slot,
- Hoisting platform (if possible)
- Installation material required for fabrication provided by Lightweight

### **Installation Step 1:**

Advance your car with the hoisting platform until you can work under the front bumper/engine cover. Solve the 2 black screws in middle of the bumper.

### **Installation Step 2:**

Take now your new Lightweight Spoilerlip and turn the bottom side above. Screw the four supplied Metalscrews complete into the the two holes in the middle of the lip.

Turn the lip and put the two black plastic sockets over the screws.

#### **Installation Step 4:**

Take your new Frontlip and drill the two screws tightly into the four oem holes of the bumper. After that the lip is fixed.

#### **Installation Step 5:**

Now drill the other delivered screws through the given holes in the lip into the bumper.

**And now have fun with your new Lightweight Frontlip!**